

The logo for MandolinMart.com is displayed in a white, elegant cursive font. It is set against a background of a building's facade with a grid of windows, and the entire scene is set against a dark red gradient background.

1-800-997-6649
MandolinMart.com

How to maintain and clean your mandolin

You should wipe the mandolin off and polish all metal and wood with cloth after every playing. Use a different cloth to wipe the strings thoroughly (be sure to clean under them). You may also want to apply a string conditioner to the strings (this will make them last longer). Change the strings every 4-6 weeks or when they feel “dirty”. Apply pencil lead to nut slots to keep them lubricated. Use extremely fine steel wool to clean and polish fingerboard and frets. Apply lemon oil to fingerboard.